

# Instellingen Turbo Chef

TM= % tijd van totale bereidingstijd

Air Top = hete lucht boven

Air Botom = hete lucht onder

WAV = Magnetron

Grp No.	Group Name	Item Name	Cook Time	Cook Settings																													
				Event #1					Event #2					Event #3					Event #4					Event #5					Event #6				
				Tm %	Top Air %	Btm Air %	Wav %	Ins	Tm %	Top Air %	Btm Air %	Wav %	Ins	Tm %	Top Air %	Btm Air %	Wav %	Ins	Tm %	Top Air %	Btm Air %	Wav %	Ins	Tm %	Top Air %	Btm Air %	Wav %	Ins	Tm %	Top Air %	Btm Air %	Wav %	Ins
1	HARTIGE BROODJES	1 x Frikandel	00:40	25	80	80	70		25	70	70	80		25	60	60	70		25	80	80	30		0	10	10	0		0	10	10	0	
		2 x Frikandel	00:50	25	80	80	80		25	70	70	80		25	60	60	60		25	80	80	40		0	10	10	0		0	10	10	0	
		3 x Frikandel	01:00	25	80	80	80		25	70	70	80		25	60	60	60		25	80	70	40		0	10	10	0		0	10	10	0	
		4 x Frikandel	01:30	25	80	80	80		25	70	70	80		25	60	60	60		25	80	70	40		0	10	10	0		0	10	10	0	
		1 x Appelflap	00:30	50	30	100	70		50	70	100	40		0	10	10	0		0	10	10	0		0	10	10	0		0	10	10	0	
		2 x Appelflap	00:50	50	30	100	70		50	70	100	40		0	10	10	0		0	10	10	0		0	10	10	0		0	10	10	0	
		3 x Appelflap	01:05	50	30	100	70		50	70	100	40		0	10	10	0		0	10	10	0		0	10	10	0		0	10	10	0	
		4 x Appelflap	01:25	50	30	100	70		50	70	100	40		0	10	10	0		0	10	10	0		0	10	10	0		0	10	10	0	

Instellingen Turbo Chef